
3.28 – Using Java parameters

In some cases, the use of Java parameters during or before the start of SparkView is useful or necessary.
Depending on the system, these must be entered as follows:

Windows

Enter the parameters in the SparkView control panel under the "Java" tab one below the other.



Linux/MacOS

Enter the parameters directly with the start command, e.g.

```
java -Dcom.sun.jndi.ldap.object.disableEndpointIdentification=true -jar SparkGateway.jar
```

Revision #3
Created 9 January 2024 13:57:23 by Julian
Updated 9 January 2024 14:09:56 by Julian